

SURFACE

Painting/re-painting STENI façade panels

BASIC INSTRUCTIONS

1. The surface must be 100% dry and free of grease, dust and loose material.
2. Areas with mould, algae or moss should be treated with a suitable cleaning agent. Contact a company specialising in cleaning services.
3. Small nicks and scratches in the surface should be repaired. An epoxy filler is recommended.
4. For best adhesion, roughen the surface with sandpaper P240 or equivalent. For surfaces of natural stone, scrub the surface with the recommended cleaning agent for the primer/acrylic paint in accordance with the product description from the paint supplier.
5. We recommend that you prime the surface to ensure optimal adhesion to the acrylic paint.
6. For the top layer, generally 2 coats of acrylic paint will cover over the colour beneath.
7. Use the right painting tools to achieve the desired end result. Contact the paint manufacturer or an authorised painting company for further guidance.

MANUFACTURER

Always consult the manufacturer's product description for the exact procedure and other documentation.

SAFETY

- Always follow the manufacturer's/product safety description.
- Use only CE marked machines with proper safety protection.
- Always use personal protective equipment such as goggles and a dust mask (min. P3).